Measuring Guide

Therearemainlytwodi erentwaysinwhichwindows will be originally installed.




BRICK to BRICK

You will see about 20-40mm of visible brick showing on the outside.

HOW TO MEASURE

Measure between the external brickwork opening and deduct 10mm both in width and height.




CHECK REVEAL

Full width of the brick visible on the outside.

HOW TO MEASURE

Measure between the external brickwork opening add 40mm to the width and 20mm* to the height with equal 20mm* sitting behind the brick.
(* Providing there is sufficient clearance to do so.)





IMPORTANT - Check the internal widthand height are larger than external.